



**easiflow<sup>®</sup>**  
**360<sup>°</sup>**  
lip activated cup



Please read and keep these instructions



Mayborn ANZ Pty Ltd. (ABN 66 154 703 134)  
PO Box 475, Mt Waverley VIC 3149  
AUSTRALIA

Newborn Brands (NZ) Ltd. PO Box 47-677  
Ponsonby Auckland 1144  
NEW ZEALAND

0248103

Copyright© Mayborn (UK) Limited 2018 - 20.  
TOMMEE TIPPEE is a registered trademark.  
Mayborn (UK) Limited retains all intellectual  
property rights to this product.



Any questions?  
Visit our website  
[tommeetippee.com](http://tommeetippee.com)

**EN** For your child's safety and health  
**WARNING!**

Always use this product with adult supervision. Accidents have occurred when babies have been left alone with drinking equipment due to the baby falling or if the product has disassembled. Continuous and prolonged sucking of fluids will cause tooth decay. Tooth decay in young children can occur even when non-sweetened fluids are used. This can occur if the baby is allowed to use the cup for long periods through the day and particularly through the night when saliva flow is reduced. Always check food temperature before feeding. Always stir heated food to ensure even heat distribution and test the temperature before serving. Keep all components not in use out of reach of children.

**CLEANING AND STERILISATION**

Before first use, clean the product. Clean before each use. Always wash the product immediately after use. Wash in warm soapy water and rinse in clean water or use a dishwasher (top shelf only). Do not clean with solvents or harsh chemicals. Do not allow product to come into contact with oil based foods (e.g. oil/tomato based sauces) as staining will occur. Cold water sterilisation only. Not suitable for sterilisation by boiling, steam or microwave.

**STORAGE AND USE**

Inspect before each use. Throw away at the first signs of damage or weakness. Do not store or leave in direct sunlight or near a source of heat. Do not store with, or allow to come into contact with solvents or harsh chemicals. Not suitable for use in a conventional oven or a combination microwave oven with the grill feature switched on. Not suitable for microwave use. As with most toddler cups the 360° cup can be used with milk, water or juices that do not contain pulp. Do not use with carbonated beverages, formula or hot liquids.

**USING YOUR EASIFLOW™ 360° CUP**

Remove the travel lid and valve. To remove the valve, grip the tab in the centre and rotate it anti-clockwise until it unlocks.

Once you've unlocked the valve, pull the valve upwards to remove for cleaning and to add liquid to the cup. When adding liquid to the cup do not fill past the fill line. Replace the valve by lining up the notches with the ribs in the cup. Push down firmly and rotate clockwise to lock the valve in place. If you're transporting liquid in the cup, secure the travel lid on top.

